

TERMET S.A.	INSTANTANEOUS GAS WATER HEATER	
ul. Długa 13 58-160 Świebodzice	WGH3920.00.00.00/EU1T	GH-19-02 TERMAQ AQUA-POWER Eco
	EPREL	

		BASIC PROFILE	ADDITIONAL PROFILE
Declared load profile		M	-----
Water heating energy efficiency class	η_{wh}	A	-----
Water heating energy efficiency		79 %	-----
Annual electricity consumption	AEC	0 kWh	-----
Annual fuel consumption	AFC	6 GJ	-----
Thermostat temperature settings	°C	-	
Sound power level	L _{WA}	53 dB	
Able to work only during off-peak hours		-----	
Any specific precautions that shall be taken when the water heater is assembled, installed or maintained			
1. Check whether the purchased water heater is factory adapted to the gas contained in the gas installation to which it is intended to be connected. 2. Water heater must not be installed in rooms where the ambient temperature may drop below 0°C. In case of danger of freezing, disconnect and empty the device from the water. 3. Water heater must not be installed above the heat source (above the electric stove, gas stove,...). 4. It is forbidden to install and start the water heater in a room where construction works are in progress. 5. After installing the water heater, tightness of all gas and water connections should be checked. 6. Water heater must be operated by an adult only. 7. Do not manipulate the components yourself, or make any repairs or alterations, especially in the safety system. 8. Do not block the supply and exhaust grilles. 9. Do not store any containers with flammable, aggressive and corrosive substances near the water heater. 10. Do not place or dry any clothing or other flammable objects on or near the devices and flue gas ducts. 11. Servicing and maintenance of the water heater may only be carried out by an authorized company.			